

POWERFLEX®

PART NUMBER

EXH030

DESCRIPTION

REAR EXHAUST MOUNT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Exhaust Mount

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original rubber bush from it's outer casing in the exhaust mounting bracket. The rubber normally becomes unbonded and can be pressed out of the casing with ease as shown in Fig 1. Alternatively, the rubber can be cut away using a hacksaw or sharp knife.
2. Clean any remaining rubber, dirt and corrosion from the bore of the metal casing in the bracket.
3. Apply some washing up liquid to the outside of the new polyurethane bush and push it into the bracket casing, taking note of its orientation as shown in Fig 2.

Fitting tips: We recommend using a G-Clamp or Bench Vice to push the bush through the bracket fully. The stiffer and less flexible Black Series material will be more difficult to fit, so more care is needed to prevent damaging the bush or bracket.



Figure 1



Figure 2