



PART NUMBER

**PF32-105**

DESCRIPTION

**ANTI ROLL BAR LINK BUSH**

### INSTALLATION GUIDE

#### **Product description:**

This part replaces OE number: 552819 and is designed to fit front or rear positions of the anti roll bar link.

#### **Contents (parts per pack):**

- 4 x Polyurethane bushes
- 2 x Steel washers
- 1 x PTFE / Silicone Bush Assembly Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
  - all safety precautions adhered to;*
  - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the original rubber bushes from the anti roll bar link.
2. Clean any dirt and corrosion from the bore of the link and from the original bolt.
3. Fit the polyurethane bushes into the link rod, apply some of the supplied PTFE / Silicone grease to the bore of each bush.
4. Fit the supplied washer onto the original bolt and push through the bush from the inside of the car.
5. Tighten all hardware to manufacturers recommended torque settings.

