

POWERFLEX®

PART NUMBER

PFF1-502

DESCRIPTION

FRONT LOWER ARM REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

4 x bushes, 2 X A bushes, 2 X B bushes

1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove front lower arm from the car. Make a note of the forward face of the bracket. Remove the rear bush and bracket from the arm, the hex on the arm pushes out of the bush.
2. Remove the bush from the bracket, caution the original bush is oil filled.
3. Chamfer the front edge, this edge is sharp and may damage the bush if not chamfered it also aids fitment of the new bush. Clean any dirt/corrosion from the bore of the bracket.
4. Apply some washing up liquid to the tapered end of the larger B bush, push the bush into the bracket from the front face so the square end is to the front of the car.
5. Apply some of the supplied grease to the bore of the B bush and the outside of the A bush.
6. Place the radius end of the A bush from the front face of the bore of the B bush and push it in until it clips into place.
7. Clean the hex of the arm and remove any sharp edges. Push the bracket and bush onto the hex.
8. Refit the arm to the car.

