

POWERFLEX®

PART NUMBER
PFF1-815

DESCRIPTION
FRONT UPPER WISHBONE BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x bushes
- 4 x stainless steel sleeves
- 4 x nylon washers
- 4 x metal washers
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the arm from the car and remove the original bushes including the outer shells.
2. Clean any dirt from the bores in the arm. Fit the new Powerflex bushes opposing each other from the outside faces.
3. Lubricate the bore of the bushes with some of the supplied grease, push the stainless steel sleeves into the bushes, push the sleeve in so it protrudes through the bush by 1.5mm.
4. Apply some of the supplied grease to the faces of the nylon washers, fit one nylon washer over the protruding sleeve on the inner face of the bush, this will sit between the bush and chassis.
5. Offer the arm back on to the car making sure the nylon washers stay in place. The metal washers fit over the larger end of the bushes before bolting the arm back in place.

