

# POWERFLEX®

## PART NUMBER

**PFF16-603-21,22**

## DESCRIPTION

**ANTI ROLL BAR TO CHASSIS BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 2 x bushes
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. The original bracket has to be pried apart to remove the original bush. Once the bracket and bush has been removed clean any dirt and corrosion from the bar and bracket. Fig. A.
2. Apply some of the supplied grease to the bar.
3. Fit the new Powerflex bush on the anti roll bar, refit the brackets around the bush



Fig. A



Fig. B



Fig. C