

POWERFLEX®

PART NUMBER

PFF16-604-13

DESCRIPTION

ANTI ROLL BAR TO ARM BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x bushes

1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the original rubber bush and bracket from the Anti roll bar. Separate the brackets using a drill on the swaged holes, being careful not to drill all the way through as shown in Fig. A.
2. Cut out the bonded rubber bush from the brackets and clean any dust/corrosion from the surface of the Anti roll bar.
3. Clean the brackets. Push the new Powerflex PU bush on the Anti roll bar and fit the brackets as shown in the Fig B.
4. Re-fit the Anti roll bar on the car and the control arm Fig. C and tension all hardware to manufacturers recommended torque settings.



Fig. A

Fig. B

Fig. C