



PART NUMBER

PFF19-1821

DESCRIPTION

LOWER ENGINE MOUNT BUSH INSERT

INSTALLATION GUIDE

Product Description:

This is an a polyurethane insert that fits into and fills voids in the original bush in bracket OE number: 5165555.

Contents (parts per pack):

1 x Polyurethane A Insert

1 x Polyurethane B Insert

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

-all work to be carried out by a licensed technician;

-all safety precautions adhered to;

-wheel alignment to be checked and adjusted as required after any suspension work.

Fitting Instructions:

1. Remove the original mounting bracket from the car.
2. Fit the polyurethane A part insert into the upper position of the mounting bracket.
3. Fit the polyurethane B part insert into the lower position of the mounting bracket.
4. Re-fit the bracket to the car and tighten all hardware to manufacturers recommended torque settings.

