

POWERFLEX®

PART NUMBER

PFF19-2026

DESCRIPTION

TRANSMISSION MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x Polyurethane A Bush Insert
- 1 x Polyurethane B Insert

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Clean any dirt and corrosion from the bores in the mount.
2. Insert the polyurethane A bush insert into the transmission mount bush from left hand side of vehicle, as shown in *Figure 1, Pt1*.
3. Insert polyurethane B insert into holes at the top of polyurethane A insert bush, making sure the non text inscribed face sits flush with the bracket. As shown in *Figure 1, Pt2*.
4. Re-fit transmission mount to the vehicle. Tension all hardware to manufacturers recommended torque settings.

Figure 1: Fitted Assembly Steps

