

POWERFLEX®

PART NUMBER

PFF25-203

DESCRIPTION

FRONT ARM REAR BUSH

INSTALLATION GUIDE

Product description:

Supplied as a single piece press in unit incorporating our unique polyurethane ball design allowing free articulation of the arm similar to a rose joint without the harshness encountered from a metal joint.

Contents (parts per pack):

- 2 x bushes
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove arm from the car, press out the original bush.

Tip: the caster adjusting bolt is known to seize in, treat well with an anti seize lubricant to aid removal.

PFF25-203-ADJ is a stainless steel caster adjusting kit made to replace the standard Honda parts so next time the geometry requires adjustment it wont be seized.

2. Fit the new bush in from the top of the arm, press the unit in until the larger diameter stops on the arm. Use a suitable spacer so you only press on the outer metal shell not the polyurethane or centre sleeve.
3. Grease the bolt and refit the arm, reset the geometry.

