

# POWERFLEX®

PART NUMBER

**PFF25-203**

DESCRIPTION

**FRONT ARM REAR BUSH**

## INSTALLATION GUIDE

### Product description:

Supplied as a single piece press in unit incorporating our unique polyurethane ball design allowing free articulation of the arm similar to a rose joint without the harshness encountered from a metal joint.

### Contents (parts per pack):

- 2 x bushes
- 1 x grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove arm from the car, press out the original bush.

*Tip: the caster adjusting bolt is known to seize in, treat well with an anti seize lubricant to aid removal.*

*PFF25-203-ADJ is a stainless steel caster adjusting kit made to replace the standard Honda parts so next time the geometry requires adjustment it wont be seized.*

2. Fit the new bush in from the top of the arm, press the unit in until the larger diameter stops on the arm. Use a suitable spacer so you only press on the outer metal shell not the polyurethane or centre sleeve.
3. Grease the bolt and refit the arm, reset the geometry.

