

# POWERFLEX®

PART NUMBER

**PFF25-301**

DESCRIPTION

**FRONT ARM FRONT BUSH**

## INSTALLATION GUIDE

### Product description:

This bush has the added benefit of additional Anti Lift geometry.

### Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the front arm from the car.
2. Remove the original bush from the arm, clean any dirt and rust away.
3. Fit PFF25-301 into the arm with the longer end downwards, towards the floor.

*Tip. Apply washing up liquid to the bush, place the bush into the arm at an angle so one edge is already started then press the bush into the arm. If you try to push the bush in square it will not go in.*

4. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush.

5. Refit the arm to the car.

