

# POWERFLEX®

PART NUMBER

**PFF3-102**

DESCRIPTION

**ALLOY WISHBONE BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x bushes
- 4 x stainless steel sleeves
- 8 x nylon washers
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original bush from the arm including the original outer shell. Clean any dirt and rust from the bore of the arm.
2. Fit the new bush in from the out side face of the arm so the smaller diameters of the bushes will be facing each other from the front and rear bush.
3. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush so the sleeve protrudes equal amounts each side.
4. Place one of the supplied nylon washers on each end of the sleeve.
5. Refit the arm back onto the car making sure the washers don't fall off.

