

POWERFLEX®

PART NUMBER

PFF3-701

DESCRIPTION

FRONT LOWER CONTROL ARM BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 4 x Plated Mild Steel Shells

2 x Stainless Steel Sleeves 4 x BZP M12 Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with a workshop manual.

It is recommended that:

- All work is to be carried out by a licensed technician.
- All safety precautions are adhered to.
- Wheel alignment is to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the arm including its outer shell.
2. Clean any dirt and corrosion from the bore in the arm, removing any sharp edges and creating a small chamfer with a rounded file.
3. Press the two plated outer shells into each side of the arm until flush.

Tip: Apply a small amount of washing-up liquid to the bush and arm, to aid fitment of the bush.

4. Press the polyurethane bush into the outer shells until properly seated.
5. Apply some of the supplied grease to the bore of the bush and press in the sleeve until flush.
6. Apply the rest of the supplied grease to the end faces of the bush and place the M12 washers on each end as the arm is presented to the vehicle.
7. Refit the arm to the vehicle and tension all hardware to the manufacturer's recommended torque settings.

