

POWERFLEX®

PART NUMBER

PFR3-702

DESCRIPTION

REAR ARM INNER BUSH, CAMBER ADJUSTABLE

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 4 x Mild Steel Washers
2 x Stainless Steel Sleeves 2 x Mild Steel Outer Shell
1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original bush including outer shell from the arm.
2. Clean any dirt, burrs and corrosion from the bore in the arm. Remove any sharp edges from the arm.
3. Press steel outer shell into bore of arm, pressing on the larger diameter face. Press till the larger diameter lip sits flush on machined face of arm.
4. Press the polyurethane bush into the bore of the shell. Apply some washing up liquid to ease this. Ensure the end of the bush with the larger offset is facing towards the rear of the vehicle.
5. Apply some provided grease to the bore and mounting faces of each bush. Fit the stainless steel sleeve into bush.
6. Place washers flush against top face of polyurethane bushes and refit arm to car.
7. Tension all hardware to manufacturers recommended torque settings.

