



PART NUMBER

PFF36-107

DESCRIPTION

ANTI ROLL BAR LINK ROD BUSH

INSTALLATION GUIDE

Product description:

This bush replaces the front and rear anti roll bar link bar bushes. Two kits will be required per car, one for the front and one for the rear.

Contents (parts per pack):

- 4 x bushes
- 4 x stainless steel sleeves
- 4 x washers
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the anti roll bar link from the car and remove the original bushes.
2. Clean any dirt/rust from the link rod, with a file remove any sharp edges from the bore of the rod.
3. Fit the bushes into the rod, apply some of the supplied grease to the bore of the bush and push the stainless steel sleeve into the bush.
4. Refit the link rod to the car, place the washer onto the open face of the bush where it bolts onto the anti roll bar.

