

# POWERFLEX®

PART NUMBER

**PFF5-201G**

DESCRIPTION

FRONT WISHBONE REAR BUSH, CASTER ADJUSTED

## Product description:

This part replaces OE number: 31126763530  
By fitting these bushes the caster is increased by 2°.

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x polyurethane bushes  
2 x aluminium outer shells

2 x polyurethane 8mm spacers  
1 x PTFE / silicone bush assembly grease



*Please read the complete fitting instructions and check package components before fitment.  
These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the front lower wishbone rear housing and bush. Remove the arm from the bush and the bush from the bracket.
2. Clean any dirt and corrosion from the bore of the bracket.
3. Place the aluminium shell into the bracket from the front face, rotate the shell so the arrows point outwards. Press the aluminium shell fully into the bracket once you are happy with the position.
4. Place the 8mm spacer onto the hex with the recess towards the wishbone, push the main bush onto the hex pin.
5. Apply some of the supplied grease to the bore of the shell and end faces of the bush and spacer.
6. Push the bracket/shell onto the bush so the head of the bush fits into the recess of the shell.
7. Refit the wishbone back onto the car.
8. Tighten all hardware to manufacturers recommended torque settings, road test and check geometry.



POWERFLEX PFF5-201G

