



PART NUMBER

**PFF57-1403**

DESCRIPTION

**Front Stabilizer Mounting Bush**

INSTALLATION GUIDE

**Contents (parts per pack):**

- 2 x Polyurethane Bushes
- 1 x Powerflex Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



**Fitting Instructions:**

1. Remove the three bolts from the bushing mount bracket to and remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Apply grease to inside of bush, open bushing and place around bar.
4. Push bushing along bar and into bushing mount.
4. Fit bushing mount and bushing to car and tighten to ensure bushing stays in place.
5. Reattach all parts to car and tension all hardware to manufacturers recommended torque settings.

