

# POWERFLEX®

## PART NUMBER

# PFF60-1422

## DESCRIPTION

### Lower Engine Mount

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x Polyurethane A Bushes    1 x PTFE/Silicone Grease  
1 x Aluminium mount with prefitted bush and sleeve  
2 x Nylon Washers                1 x Stainless Steel Sleeve

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

### Fitting Instructions:

1. Press the 2 black Polyurethane bushes into either side of the smaller end of the black aluminium mount.
2. Apply the supplied grease to the outside of the stainless steel sleeve, and press it into the bush at the smaller end of the mount.
3. Apply the supplied grease to both faces of both bushes on the mount.
4. Slip the nylon washers over either end of the smaller sleeve.
5. Remove the Renault lower engine mount and bracket assembly by unbolting the bracket from the gearbox, and removing the bolt from the subframe.
6. Unbolt the Renault mount from the bracket, and replace with PFF60-1422 by bolting the smaller end into the bracket.
7. Replace the new mount/bracket assembly on the car, and tension all hardware to manufacturers recommended torque settings.

