

POWERFLEX®

PART NUMBER

PFF60-703-22.5

DESCRIPTION

Front Antiroll Bar Bush - 22.5mm

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove antiroll bar from vehicle
2. Remove antiroll bar brackets and spacers from the bar.
3. Remove the original rubber bushing from the bar. This bushing is bonded to the bar, so will need to be cut/torn off.
4. Scrape off any remaining rubber or glue from the bar.
5. Fit PFF60-703-22.5 onto the bar where the original bush was located.
6. Push metal bracket over PFF60-703-22.5 and slide in the plastic spacer.
7. Refit the antiroll bar to the subframe, and tension all hardware to manufacturers recommended torque settings.

