

# POWERFLEX®

PART NUMBER

## PFF60-8025

DESCRIPTION

## LOWER TORQUE MOUNT

### INSTALLATION GUIDE

#### Contents (parts per pack):

- 1 x Aluminium Bracket with Prefitted Bushes
- 1 x PTFE/Silicone Grease
- 1 x Stainless Steel Washer 1 x Mild Steel Washer

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

#### Fitting Instructions:

1. Remove OEM mount from vehicle.
2. Apply supplied grease liberally to both faces of both bushes and both sides of stainless steel washer.
3. Push the washer into the recess on the larger bush, with the curved edges facing in towards the bush.
4. Fit the bracket in place on the car, with the washer side facing upwards inside the subframe.
5. Place the mild steel washer onto the bolt that will be securing the smaller end of the mount to the gearbox, and then mount this bolt in place
6. Replace all bolts and tighten to manufacturers' recommended torque settings.

