

# POWERFLEX®

PART NUMBER

## PFF60-8026P

DESCRIPTION

## LOWER TORQUE MOUNT

### INSTALLATION GUIDE

#### Contents (parts per pack):

- 1 x Aluminium Bracket with Pre-fitted A and B Bushes
- 2 x Mild Steel Washers
- 1 x PTFE/Silicone Grease
- 1 x Short Stainless Steel Sleeve
- 1 x Polyurethane Bush C
- 1 x Long Stainless Steel Sleeve

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



#### Fitting Instructions:

1. Remove OEM mount from vehicle.
2. Apply supplied grease liberally to both faces of both bushes.
3. Fit the short stainless steel sleeve into Bush A.
4. Fit Bush C into Bush B and then insert the longer stainless steel sleeve.
3. Place a washer on either side of the larger bush ensuring the bores align with the sleeve bores.
4. Fit torque mount to car, ensuring the washers stay in place.
5. Refit all bolts and tighten to manufacturers' recommended torque settings.

