

POWERFLEX®

PART NUMBER

PFF76-402K

DESCRIPTION

FRONT WISHBONE REAR ANTI LIFT KIT

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes	4 x Spring Washers
2 x Mild Steel U-Brackets	4 x Washers
4 x Bolts	2 x Anodised Aluminium Spacers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the suspension arm from the vehicle and press/cut off the original bush from the arm. The original bush inner metal sleeve **MUST BE** removed from the wishbone, exposing the bare stub/pin. The stub/pin on the wishbone needs to be clean and smooth prior to installing our bush as this becomes the rotation point.

2. Apply some of the supplied grease to the stub/pin on the wishbone and bore of the bush, with the offset hole positioned towards the outside of the vehicle.

3. Refit the wishbone to the vehicle.

4. Fit the bracket onto the bush, with the aluminium spacing plate sandwiching between the bracket and floor of the vehicle, bolting it into position with the supplied bolts and washers as shown in Fig. 2. Tighten to the OE manufacturers recommended torque settings.

5. Check alignment, adjusting if necessary and road test.



Figure 2 Assembly

