

POWERFLEX®

PART NUMBER

PFF76-604

DESCRIPTION

TOYOTA SUPRA FRONT UPPER WISHBONE BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 8 x Polyurethane Bushes
- 4 x Stainless Steel Sleeves
- 4 x Zinc Plated Mild Steel Washers
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tightened to manufacturer's torque settings.



Fitting Instructions:

1. Remove the upper wishbone from the car.
2. Press out the original bushes including any outer shells from the wishbone.
3. Clean away any corrosion or dirt from the vacant bore.
4. Press the bushes into either side of the arm.
5. Apply the supplied grease to the bore and outside faces of the bushes and push in the stainless steel sleeve.
6. Offer the wishbone back up to the car, and place the supplied washers in between the bush and the subframe.
7. The original washers should be retained and refitted to the outside of each bush.
8. Refit the nut and bolt, and tension all hardware to the manufacturers recommended torque settings.

