

POWERFLEX®

PART NUMBER

PFF80-1101

DESCRIPTION

FRONT ARM FRONT BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x bushes, 2 x A parts, 2 x B parts
- 2 x metal sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove arm from car, note the original bush is offset with a larger section towards the rear of the arm.
2. Remove the original bush from the arm and clean away any rust or residue left.
3. Insert the polyurethane bush marked PFF80-1101A from the rear of the arm and the polyurethane bush marked PFF80-1101B from the front, this will replicate the offsets on the original bush.
4. Apply some of the supplied grease to the bore of the bush and to the outside of the stainless steel sleeve, push the sleeve into the bush. Smear some of the grease over the end faces of the bush.
5. Refit the arm to the car.

