

POWERFLEX®

PART NUMBER

PFF80-1202

DESCRIPTION

FRONT LOWER ARM - REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x metal sleeves
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove front lower arm, remove the bolt holding the rear bush to the arm, remove the bush and bracket from the arm. Make sure you don't lose the conical spacer.
2. Remove the bush from the alloy bracket.
3. Push the bush into the bracket. Apply some of the supplied grease into the bore of the bush.
4. Make sure the conical spacer is still on the pin of the arm, slide the stainless sleeve onto the pin.
5. Slide the bush and bracket onto the arm, make sure the concave end of the bush goes onto the pin first (please note this turns the bracket around). Refit the original bolt and washer
6. Refit the arm to the car

