



PART NUMBER

PFF85-1007

DESCRIPTION

FRONT RADIUS ROD BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x Polyurethane A Bush
- 2 x Polyurethane B Bush
- 2 x Alloy Cap
- 2 x Stainless Steel Sleeve
- 1 x Powerflex Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

Please Note: The radius arm controls the caster angle and therefore measuring the length of the rod between the lower arm and chassis is advised so that the caster angle can be kept constant after the bush change.

1. Remove the radius rod from the vehicle. On later vehicles the radius rod is screwed into the lower arm whereas on earlier vehicles the radius rod is bolted to the lower arm.
2. Remove the original bushes and remove any corrosion or sharp edges from the bore.
3. Press the Alloy Cap onto Polyurethane Bush A in the orientation shown in Figure 1. Then press both bushes into the bore of the arm.
4. Apply some of the supplied grease to the bore of the bush and press the sleeve into the bushings in the direction indicated in Figure 1.
5. Place a washer on the end of each bush in the orientation shown in Figure 1 and then reattach to vehicle.
6. Tighten all fasteners to manufacturers torque settings.

Figure 1

