



PART NUMBER

PFF85-1108

DESCRIPTION

FRONT ANTI ROLL BAR LINK ROD TO ARM

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 4 x washers
- 2 x stainless steel sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the front anti roll bar link rod from the vehicle.
2. Remove the bush which connects the link rod to the arm.
3. Push the new bush into the link rod.
4. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush.
5. Refit the link rod back onto the vehicle. Before bolting the bush to the arm fit the supplied washers to either side to support the bush. Fit the bolt and tighten.

