

POWERFLEX®

PART NUMBER

PFF85-402

DESCRIPTION

FRONT ARM REAR BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 4 x spacers
- 4 x metal washers, shaped slot
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the front lower arm from the car, remove the rear bush including the outer shell from the arm. Clean the arm of any dirt and rust.
2. Place the smaller diameter end of the new bush into the radius face of the arm and push the bush in, make sure the lip comes out of the other side of the arm.
3. Apply some of the supplied grease to the bore of the bush, push the sleeve into the bush.
4. Before refitting the arm to the car, the supplied collars and washers will need to be fitted to the subframe. Fit one collar into the upper bolt hole and one into the lower hole, fit the shaped washers onto the horse shoe shaped ridges in the subframe. It may be easier to apply some grease to hold these in position.
5. Refit the arm to the car.

