

POWERFLEX®

PART NUMBER

PFF88-1030

DESCRIPTION

LOWER ENGINE MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Bush

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original mount, ensuring to retain all original hardware.
2. Insert the Polyurethane Bush into the voids of the original bush, until the bush sits flush. The insert should go in from the rear of the mount and hold between the mount and mounting bracket.

