



PART NUMBER

**PFR1-714**

DESCRIPTION

REAR LOWER SPRING MOUNT OUTER

INSTALLATION GUIDE

**Contents (parts per pack):**

4 x Bushes                      2 x Stainless steel sleeve  
1 x Grease                      4 x Washers



*Please read the complete fitting instructions and check package components before fitment.*

*These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the original bush from the arm.
2. Clean any dirt and corrosion from the bore in the arm.  
Remove any sharp edges from the bore of the arm.
3. Insert bushes into arm.
4. Apply grease into bore of the bushes.
5. Fit sleeve into bush.
6. Washers should be fitted to the outside of the top hats to support the bush.
7. Refit arm.

