

POWERFLEX®

PART NUMBER

PFR1-816, 817 & 818

DESCRIPTION

REAR SUSPENSION BUSHES

INSTALLATION GUIDE

Product description:

PFR1-816 - REAR SUSPENSION FRONT ARM BUSH

PFR1-817 - REAR SUSPENSION REAR ARM BUSH

PFR1-818 - REAR TIE BAR TO HUB BUSH

Fitting Instructions:

Thank you for purchasing one of the advanced ranges of POWERFLEX polyurethane suspension bushes.

These bushes should be fitted with the supplied washers which are to be fitted on the “top hat” face of the bush. Fit the nylon washer against the bush and the metal washer against the nylon one where applicable.

On certain model cars washers may not be required if the bushes are to be mounted between two chassis faces. Always use a washer where there is no plate against the face of the bush.

Where not fitted between two chassis faces, use large dia washer on outside face.

Always check suspension alignment after fitting POWERFLEX bushes.

Should you experience any technical difficulties in any way please contact our technical Hotline.

