

### INSTALLATION GUIDE

#### **Product description:**

This part replaces OEM part number 81AB-18198-AA.

#### **Contents (parts per pack):**

2 x Polyurethane Bushes

1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the rear shock from the car.
2. Remove the original shock mount bush and washers from the shock. Fig A.
3. Clean any dirt and corrosion from the washers and the top of the shock.
4. Fit the new PU bush with the original washers on the shock. Fig B.
5. Re-fit the rear shock to the car. Tension all hardware to manufacturers recommended torque settings.



Fig A.



Fig B.