

POWERFLEX®

PART NUMBER
PFR25-209

DESCRIPTION
REAR UPPER ARM INNER BUSH

INSTALLATION GUIDE

Product description:

This bush fits the Honda S2000 from 2004 to 2009 where the diameter of the hole in the arm measures 42mm with a length of 57mm, please use PFF25-210 for smaller 35mm diameter by 47mm long bushes

Contents (parts per pack):

- 8 x bushes (4 A parts & 4 B parts)
- 4 x metal sleeves
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the arm from the car, remove the original bushes from the arm including the outer shell.
2. Clean any dirt from the hole, check you have the correct size bush PFR25-209 fits a 42mm bore hole, for a 35mm bore use PFR25-210.
3. For each bush you need 1 x A part & 1 x B part, the A part (thicker large diameter) fits from the outside of the arm and the B part (thinner large diameter) fits from the inside of the arm in all 4 positions.
4. Push the bushes into the arm, lubricate the bore of the bush and the outside of the stainless steel sleeve with the supplied grease and push the stainless steel sleeve through the bush.
5. Once all the bushes are fitted apply some grease to the end faces of the bushes and refit the arm back onto the car.