



PART NUMBER

PFR3-270

DESCRIPTION

AUDI A4 REAR DIFF FRONT MOUNTING BUSH

INSTALLATION GUIDE

Product description:

This bush offers reduced movement of the rear diff which results in a reduction of the initial torque lost during acceleration.

Contents (parts per pack):

- 1 x A part polyurethane bush
- 1 x B part polyurethane bush
- 1 x Stainless steel sleeve
- 1 x Grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bush from the bracket once the bracket has been removed from the car. Clean any dirt or corrosion from the bore of the bracket and the mounting faces of the diff.
2. Fit the A part of the bush into the bracket from the left hand side of the car. Fit the B part of the bush into the bracket from the right hand side of the car, aligning the cut-out feature with the cast features on the bracket.
3. Apply some of supplied grease to the bore and both ends of the bush and insert the sleeve into the bush.
4. Re-fit the bracket to the car and tighten to bolts to manufacturers recommended torque settings.

B Bush



A Bush



Align B bush with cast features on bracket