



PART NUMBER  
**PFR32-412**

DESCRIPTION  
**REAR UPPER WISHBONE FRONT BUSH**

### INSTALLATION GUIDE

#### **Contents (parts per pack):**

- 4 x Polyurethane bushes
- 2 x Stainless steel sleeves
- 1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*



#### **Fitting Instructions:**

1. Remove original bush from the front position of the upper wishbone, clean any dirt and rust from its bore.
2. Push in one half of the new polyurethane bush into the bore of the wishbone, aligning the arrows on the bush with the wishbone.
3. Fit the other half of the new polyurethane bush to the wishbone, again aligning the arrows on the bush with the wishbone.
4. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush.
5. Refit the wishbone to the car and tension all hardware to manufacturers recommended torque settings.



Align arrows on bush with wishbone