



PART NUMBER

PFR36-311

DESCRIPTION

DIFF TO CROSS MEMBER MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

2x A PU, 2x B PU, 2 x Sleeves, 1 x Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove the diff to cross member mount from the car.
2. Push out the original bushes from the mount.
3. Clean any dirt and corrosion from the bore of the mount.
4. Insert 'A' PU with the thicker lip from the outside of the mount and 'B' PU with the thinner lip from the inside of the mount. Fig A.
5. Apply some of the supplied grease into the bore of the bushes and insert the stainless steel sleeve into the bore.
6. Fit back mount to the car. Tension all hardware to manufacturers recommended torque settings.

