

PART NUMBER

PFR36-630

DESCRIPTION

REAR DIFF MOUNT INSERT

INSTALLATION GUIDE**Product description:**

This rear diff mount insert only fits manual cars.

The inserts fit into the voids of the original rear diff mount bush for OEM part number NA5F 39730 (Manual Version). Fitting the inserts limits movement of the diff, providing improved power delivery and stability under acceleration.

Contents (parts per pack):

2 x A Inserts

2 x B Inserts

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

-all work to be carried out by a licensed technician;

-all safety precautions adhered to;

-wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Undo bolts and lower the rear diff mount away from the sub-frame to access the diff mount bushes. Clean any dirt from the rubber bush outer and inner voids.

2. Slide the new 'A' Insert into the voids from the outside of the mount bush and 'B' Insert into the voids from the inside of the mount. Repeat same on the other side of the Rear Diff mount.

3. Refit the diff mount back to the sub-frame and tension all hardware to manufacturers recommended torque settings.

