



PART NUMBER  
**PFR42-614**

DESCRIPTION  
**Rear Toe Link Arm Bush**

### INSTALLATION GUIDE

#### **Product description:**

This part replaces OEM part number RGX000860

#### **Contents (parts per pack):**

4 x A bushes, 4 X B bushes  
4 x stainless steel sleeves  
1 x grease

*Please read the complete fitting instructions and check package components before fitment.  
These fitting instructions are to be used as a guide and in conjunction with workshop manual.  
It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the bushes from the rear toe link arm.
2. Position bush B first into the arm bore from the bottom of the arm, then align and push bush A from the top side of the arm to slide over and fit on Bush B.
3. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush.
4. Re-fit the rear toe link arm to the car and tension all hardware to manufacturers recommended torque settings.

