

# POWERFLEX®

PART NUMBER

**PFR5-1226**

DESCRIPTION

**REAR DIFF REAR MOUNTING BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 1 x bush
- 1 x stainless steel sleeve
- 1 x washer
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original bush from the subframe. Clean any dirt or rust from bore in the subframe.
2. Push the bush in from the front face of the subframe, side of the diff. Apply some of the supplied grease to the bore of the bush.
3. Push the sleeve into the bush so it sits flush with the lower face of the taper in the end of the bush.
4. Align the diff and refit the bolt with the new washer through the bush and tighten.

