



PART NUMBER

**PFR5-315**

DESCRIPTION

**REAR ANTI ROLL BAR LINK TO ARM BUSH**

**INSTALLATION GUIDE**

**Product description:**

This bush fits into the rear anti roll bar link rod that connects the anti roll bar to the arm of the car. This particular bush fits into link rod to connect it to the arm. This product is designed to complement PFR5-316 that connects the link rod to the anti roll bar.



**Contents (parts per pack):**

- 4 x Polyurethane Bushes
- 2 x Stainless Steel Sleeves
- 1 x Grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the original bush from the link rod, clean any dirt and corrosion from the bore of the link rod. A blow torch may be necessary to burn the old rubber bush out of the link rod.
2. Push in the bushes into the end of the link rod. Apply some of the supplied grease to the bore and both ends of the bush and insert the sleeve.
3. Refit the link rod to the car into the arm using the original bolt. Tension all hardware to manufacturers recommended torque settings.

PFR5-316  
Fits Onto  
Anti Roll Bar



**PFR5-315  
Fits Into Arm**