

POWERFLEX®

PART NUMBER
PFR5-325

DESCRIPTION
BMW E36 REAR DIFF FRONT MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

1 x Polyurethane Bush 1 x PTFE/Silicone Grease
1 x Stainless Steel Sleeve 1 x Mild Steel Washer

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



Fitting Instructions:

1. Remove front diff mounting bolt and lower the diff to allow access to the bush.
2. Remove the original bush from the sub-frame including its outer casing. Clean any dirt or corrosion from the bore in the subframe and the mounting face of the diff.
3. Insert the bush into the subframe with the largest diameter facing outwards, towards the front of the car. The smallest diameter fits against the mounting face of the diff.
4. Apply some of the supplied grease to the bore and both end faces of the bush and insert the sleeve.
5. Place the larger washer on the larger flange face of the bush, and the smaller washer on the smaller flange, sitting up against the diff.
6. Raise the diff back into position, and tighten to the manufacturers recommended torque settings.

