



PART NUMBER

PFR-5-326

DESCRIPTION

BMW E36 REAR DIFF REAR MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2x Polyurethane A bushes
- 2 x Polyurethane B bushes
- 2 x Aluminium sleeves
- 1 x PTFE / Silicone Bush Assembly Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove both rear diff mounting bolts and lower the diff to allow access to the bushes. Remove the original bushes from the diff mounting and clean any dirt or corrosion from inside each bore.
2. Fit the A part polyurethane bush into the diff mounting from the front of the car and fit the B part polyurethane bush into the diff mounting from the rear of the car.
3. Apply the supplied PTFE / Silicone grease to the bore and mounting faces of each bush and insert the aluminium sleeve into the B bush, from the rear of the car.
4. Raise the diff into its original position and tighten all hardware to manufactures recommended torque settings.

