



PART NUMBER

**PFR5-712**

DESCRIPTION

**REAR UPPER ARM INNER BUSH**

### INSTALLATION GUIDE

#### **Contents (parts per pack):**

- 4 x bushes
- 2 x outer shells
- 2 x stainless steel sleeves
- 1 x grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*

*All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the arm from the car. Make a note of which side of the arm the longer side of the bush protrudes from.
2. Remove the original bush. Clean any dirt or corrosion from the arm.
3. Press the outer shell in from the longer side until it stops on the second ridge, this leaves more shell protruding from the arm.
4. Fit one bush in from either side of the shell. Apply some of the supplied grease to the bore of the bush.
5. Push the sleeve into the bush.
6. Refit the arm to the car.

