



PART NUMBER

PFR5-715

DESCRIPTION

REAR OUTER INTEGRAL LINK UPPER BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x outer shells
- 2 x stainless steel sleeves
- 4 x washers, 2 x nylon & 2 x metal
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the link from the car, press out the original bush.
2. Press the new outer shell into the link, place the smaller diameter end into the radius face, press in until the smaller diameter is flush with the end of the hole.
3. Push the bush into the outer shell, the same way as above. Apply some of the supplied grease to the bore and end faces of the bush. Push the sleeve into the bush, it will protrude 1.5mm out of the smaller end.
4. Place the nylon washer onto the protruding sleeve, refit the link back onto the upright, the nylon washer sits between the bush and upright.
5. Fit the new metal washer onto the original bolt, refit bolt and complete the refitting of the link to the car.

