



PART NUMBER

PFR60-310

DESCRIPTION

REAR BEAM MOUNTING BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x outer shells
- 2 x bushes
- 2 x stainless steel sleeves
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove original bush from the rear beam.
2. Clean any dirt and rust from around the hole.
3. The outer shell needs to be pressed into the beam from the inside towards the outside so leaving the larger end face of the shell against the inside of the beam.
4. Push the new bush into the shell again from the inside. Apply some of the supplied grease to the bore of the bush.
5. Push the stainless steel sleeve into the bush.
6. Refit the beam to the car.

