

# POWERFLEX®

PART NUMBER

**PFR69-122**

DESCRIPTION

**REAR DIFF MOUNT**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x Polyurethane Bushes
- 1 x PTFE/Silicone Grease
- 2 x Stainless Steel Sleeves
- 2 x Zinc Plated Mild Steel Washers

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original bush from the mount.
2. Clean any dirt and corrosion from the bore of the mount and file off any sharp edges.
3. Insert the polyurethane part into the mount until the top hat section sits on the surface of the mount.
4. Insert another polyurethane part into the mount from the opposite side.
5. Apply some of the supplied grease to the bore of the polyurethane bush and insert the steel sleeve into the bore until it sits flush within the parts.
6. When refitting the mount, place a washer on the surface of the bush, closest to the rear of the car.
7. Tension all hardware to manufacturers recommended torque settings.



*Figure 1- Fully fitted bush including washer placed near the rear of the car*