

POWERFLEX®

PART NUMBER

PFR69-124

DESCRIPTION

REAR SUBFRAME BUSH - RIGHT HAND SIDE

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x Polyurethane A Bush
- 1 x PTFE/Silicone Grease
- 1 x Polyurethane B Bush
- 1 x Stainless Steel Sleeves

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bush from the right hand side rear subframe.
2. Clean any dirt and corrosion from the bore of the arm, and file off any sharp edges.
3. The polyurethane part with the marking PFR69-124A is the thicker upper bush. Push this bush into the bore of the arm from the top.
4. The polyurethane part marked PFR69-124B is the thinner lower bush. Push this bush into the bore of the arm from below.
5. Re-position the subframe.
6. Apply some of the supplied grease to the bore of the polyurethane parts, and push in the stainless sleeve so it sits flush.
7. Reassemble the subframe using the original parts and tension all hardware to manufacturers recommended torque settings.



Figure 1. Original Rear Subframe Mount