

POWERFLEX®

PART NUMBER

PFR69-830

DESCRIPTION

REAR DIFF REAR LEFT MOUNT INSERT

INSTALLATION GUIDE

Contents (parts per pack):

- 1 x Insert
- 1 x washer

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Support rear diff. Remove the two bolts from the left hand rear mount.
2. Apply some of the supplied grease to the legs of the insert.
3. Orientate the insert to correctly fit the voids in the original bush, the lower void is slightly bigger. Push the insert into the voids, if the insert wont go all the way home there may be a very thin rubber flashing 3/4 of the way down the voidings, this will need to be trimmed out of the way if the insert wont push through it.
4. Place the supplied washer over the insert and refit the bolts.

