

POWERFLEX®

PART NUMBER

PFR76-413-*

DESCRIPTION

Rear Anti Roll Bar Bush

INSTALLATION GUIDE

Contents (parts per pack):

2 x Polyurethane Bushes 1 x PTFE/Silicone Grease
2 x Clamps

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove rear anti roll bar from the car.
2. The original brackets and bolts need to be reused.
3. Remove the original bush, clean any rust, dirt, or remaining rubber from the bar and brackets.
4. Apply some of the supplied grease to the bore of the new bush, fit the bush over the bar, place the original bracket over the bush.
5. Refit the anti roll bar back to the car. The bolts will secure the bracket around the bush.
6. After refitting the anti roll bar, loosely assemble the clamps over the anti roll bar close to the circular face of the fitted bush.
7. Place the clamp flush against the circular face of the fitted bush and tighten both bolts to recommended torque.



Figure 1 - Disassembly



Figure 2 - Refitted