

# POWERFLEX®

## PART NUMBER

# PFR79-110

## DESCRIPTION

## REAR DIFF MOUNTING FRONT BUSH

## INSTALLATION GUIDE

### Contents (parts per pack):

2 x Polyurethane Bushes      1 x PTFE/Silicone Grease

2 x Stainless Steel Sleeves

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;*
- all safety precautions adhered to;*
- wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*



### Fitting Instructions:

1. Remove the original rubber bush from the arm, clean any dirt and corrosion from the bore in the arm. Using a file remove any sharp edges from around the bore of the arm creating a small chamfer.
  2. Check the stainless steel sleeve is not in the bush. Apply some washing up liquid to the outside of the bush to ease fitting. Press the polyurethane bush into the arm. Make sure the lip has popped out the other side of the arm.
- Tip. Insert the bush into the arm at an angle so that one part of the lip is already in the bore of the arm, so when the bush is pushed in the rest will follow.
3. Apply some of the supplied grease to the bore of the bush and insert the stainless steel sleeve into the bush.
  4. Re-fit the arm to the car and tension all hardware to manufacturers recommended torque settings.



*File small  
chamfer*